

Document No.: PBL-OI-288DP

2.88" (2 7/8") DUAL PORTED PBL BYPASS SYSTEM

Receiving PBL at Rigsite

- 1. On receipt of PBL Tools at Rigsite, the tools should be checked for the following:
 - PBL Serial Numbers located on ID band below ports on main body
 - Confirm rig end connections are as required
 - Confirm ball box matches tool size and number. Operating Instructions are included ball box
 - Shearing pressures for ball seat (Deactivation Pressure) and ports (Unlocking Pressure) are marked on tool and also on Tech Sheet included in packet
 - Confirm PBL activation ball will drift through drill string above PBL Tool
 - Confirm PBL No-Go will allow passage of required third party activation balls
 - It is recommended to drift third party ball thru PBL prior to inclusion in BHA
 - Remove tape covering PBL ports prior to RIH
- 2. If surface test is required, please contact your BICO Representative for instructions
- 3. If lock open will be required, please see PBL Auto-Lock Instructions in ball box or on website

Activation Procedure

| 1. | Prior to activating the tool, Record Pump Pres | sure Pu | ımp Strokes _ | |
|----|--|--------------------|---------------|--|
| | This will be used as a reference to confirm de-act | vation of the tool | | |

- 2. Calculate the fluid displacement **volume and time** in the drillstring to estimate when the activation ball will reach the Bypass Tool
 - Break drillstring at floor and drop one (1) 7/8" (or 1") vinyl activation ball
 - It is recommended to fill the drill string with fluid prior to dropping the activation ball
- 3. Displace 70% of the volume inside the drillstring at normal drilling rates, and then reduce the pump rate to 25% (Max. 75 GPM) until the ball lands on the seat
 - The vinyl ball will often seat sooner than the calculated pump strokes
 - The vinyl activation ball has an equivalent density of 11.2 PPG drilling fluid
 - NOTE: Care should be taken when pumping the vinyl ball down. Pumping the activation ball on seat at high fluid rates or pressures may cause the activation ball to blow through the seat
 - In the event the ball does get blown through the seat, as indicated by pump pressure/strokes the same as step one, follow De-Activation Procedure below to ensure the vinyl activation ball has gone through the seat. This step must be done prior to dropping another activation ball
 - Repeat the normal tool activation process to open the tool

| Date Issued: 07/01/2014 | Revision Number: | 2 | Page 1 of 4 |
|--------------------------|------------------|------------|------------------------|
| Issued By: Richard Earle | Revision Date: | 07/01/2017 | Doc. No.: PBL-OI-288DP |



Document No.: PBL-OI-288DP

- 4. When the activation ball lands on-seat, the Sleeve will shift to its open position against the spring with pump pressure. The activation ball will not float off of the seat if pumping is discontinued
 - NOTE: IT TAKES LESS THAN 250 PSI TO ACTIVATE /OPEN THE TOOL
 - Surface indication of the tool being in the open position is a pressure drop. Compare pump pressure/strokes to rates and pressures recorded in step one. Once the tool is open, pump rates can be increased to the desired rate above the ball deactivation shearing pressure. High pump rates/PSI will not push the ball through the seat and deactivate the tool. The deactivation pressure, marked on the tool and on Tech Sheet, only applies after the steel balls have been dropped to deactivate the tool
 - Fluid will now be diverted through the side ports. As long as pumping is continuous, fluid will be diverted through the ports. If pumping is halted, the sliding sleeve will shift to the closed position. When pumping resumes, the sleeve will shift open again allowing fluid diversion through the ports of the PBL Tool
 - It is recommended a constant, high pump rate be maintained while the tool is in the open position. If low flow rates, low differential pressures between drill pipe and annulus, bullheading, squeezing or similar low flow operations are required, it is recommended to deactivate the PBL Tool before commencing such operations
 - Rotating and reciprocating the drillstring is good practice while activating and deactivating the PBL Tool

De-Activation Procedure

- 1. Break the drillstring at rig floor and drop 2 steel 13/16" (or 7/8") de-activation balls. It is good practice to drop the second steel ball 5-10 seconds after the first one
- 2. After dropping the steel de-activation balls, immediately start pumping at 50% of the normal flow rates (75 GPM minimum) keeping the pump pressure 1000 psi below PBL deactivation pressure and watch for a pressure increase
 - When the steel balls reach the PBL Tool, they will restrict flow through the ports creating an immediate pressure increase. Bring the pressure up as quickly as possible. Do not slow or stop flow rates
 - \bullet The vinyl ball should blow through the seat at +/- 10% of stated shear pressure depending upon down hole conditions
 - A pressure decrease is an indication the vinyl activation ball has blown through the seat and into the ball catcher. The steel balls will follow into the ball catcher
- 3. After the vinyl ball shears through the seat, the sleeve will move to the closed position. Circulation will now be through the BHA
- 4. When pumping is resumed, check that the pressure and strokes are the same as they were prior to activating the PBL Tool (See data recorded in step one, above)

NOTE: After tripping out of the hole, the balls must be removed from the ball catcher sub before RIH again. **The used vinyl activation balls should be immediately discarded and NEVER RE-RUN.** It is not recommended to TIH with balls in cage

| Date Issued: 07/01/2014 | Revision Number: | 2 | Page 2 of 4 |
|--------------------------|------------------|------------|------------------------|
| Issued By: Richard Earle | Revision Date: | 07/01/2017 | Doc. No.: PBL-OI-288DP |



Document No.: PBL-OI-288DP

If required, ensure float valve is in BHA below PBL or finger trap has been installed in cage to prevent movement of balls. Consult BICO if situation arises. If the PBL sub is to be rerun after being activated, it is strongly recommended to deactivate the tool prior to tripping out of the hole

Emergency Weighted Darts with Vinyl Balls or "Fast Darts"

Not available for this tool size

Should there be any questions regarding the operational procedures of the PBL Tool please contact BICO Drilling Tools or visit our website at: **www.bicodrilling.com**

Contacts: BICO Drilling Tools, Inc

Corporate Headquarters and Service Center - Houston, Texas

1604 Greens Road Houston, TX 77032

Phone: 281-590-6966, 877-779-2426

Fax: 281-590-2280

e-mail: sales@bicodrilling.com

Southeast Service Center Broussard, Louisiana

303 Ida Road Broussard, LA 70518

Phone: 337-839-1133 Fax: 337-839-1143

Mid-Continent Service Center Oklahoma City, Oklahoma

1901 S.E. 22nd Street Oklahoma City, OK 73129

Phone: 405-677-5877 Fax: 405-677-5218

Rocky Mountains Service Center Casper, Wyoming

1849 Pyrite

Casper, WY 82604

Phone: 307-237-1420, 888-437-1420

Fax: 307-237-1419

Permian Basin Service Center Midland, Texas

3707 S. County Rd. 1210 Midland, TX 79706

Phone: 432-563-3500 Fax: 432-563-1300

Northeast Service Center Buckhannon, West Virginia

271 Weatherford Blvd. Buckhannon, WV 26201

Phone: 304-460-7304 Fax: 304-460-7307

| Date Issued: 07/01/2014 | Revision Number: | 2 | Page 3 of 4 |
|--------------------------|------------------|------------|------------------------|
| Issued By: Richard Earle | Revision Date: | 07/01/2017 | Doc. No.: PBL-OI-288DP |



Document No.: PBL-OI-288DP

PBL OPERATIONAL SEQUENCE


PBL ACTIVATION



Drilling Mode FLOW to BIT



Activation Ball Seated



Open Position FLOW THRU PORT

PBL DEACTIVATION



De-Activation Balls Dropped PRESSURE UP



Balls Sheared Thru Seat Tool Reset



Drilling Mode FLOW to BIT

| Date Issued: 07/01/2014 | Revision Number: | 2 | Page 4 of 4 |
|--------------------------|------------------|------------|------------------------|
| Issued By: Richard Earle | Revision Date: | 07/01/2017 | Doc. No.: PBL-OI-288DP |